



## **DECO PEBBLE APPLICATION FAST AND EASY**



### **FIRST DAY-STEP 1:**

We mix every sack of Decopebble (25kg) with 5kg cement, gray or white.



### **FIRST DAY-STEP 2:**

We apply on concrete sub-base the mix of Decopebble.

- a) We apply minimum 2 cm (31,5kg/m<sup>2</sup>) Decopebble (wet-on-wet) on fresh concrete surface, which we have left to absorb the water.
- b) We apply minimum 4 cm (63kg/m<sup>2</sup>) Decopebble on old concrete surface, on which we have applied earlier a coat of Polystyle.



### **FIRST DAY-STEP 3:**

We apply the mix.



### **FIRST DAY-STEP 4:**

We make the surface smooth and leave the mix to absorb the surface water.



**FIRST DAY-STEP 5:**

We spread the surface with Style Lack and cover the surface with nylon.



**SECOND DAY-STEP 6:**

We rinse the surface, using water pump and fresh water.



**SECOND DAY-STEP 7:**

Decopble Floor is ready and we can apply Style Sealer, when the surface is dry.



Visit our website: [www.stylebeton.com](http://www.stylebeton.com) for more information and videos about all our products.